

1. Available firmware, archives and documentation

Firmware

Mhx file
IL-NT-MRS16-1.0.1.mhx
IL-NT-MRS11-1.0.1.mhx
IL-NT-MRS15-1.0.1.mhx
IL-NT-MRS10-1.0.1.mhx

Archives

Archives
IL-NT-MRS16-1.0.ail
IL-NT-MRS11-1.0.ail
IL-NT-MRS15-1.0.ail
IL-NT-MRS10-1.0.ail

Documentation

PDF files	Description
IL-NT-MRS-1.0.pdf	Manual for IntelliLite NT MRS gen set controller
IL-NT-MRS-1.0.1 New features.pdf	List of new features for software update version 1.0.1

2. Main changes in IL-NT-MRS-1.0.1

Repairs

Reactive power

Reactive power was indicated with wrong (opposite) sign.

Controller LCD

Controller LCD inicialization was changed to avoid symbols and lines being burned into LCD.